



INSTALLATION INSTRUCTIONS

Description:	Rear Brake Clevis	Part Number:	990A0-85003
Application:	2005-2008 RM-Z450.	Installation Time:	.25 Hours
Note:		Weight:	.1 lbs.

Contents

Ref.	Part Number	Description:	Qty:
1	990A0-85003	Rear Brake Clevis	1



Tools Required

Ref	Tool Description
1	10mm Open End Wrench
2	Pliers
3	Torque Wrench

Important

⚠ WARNING

CAUTION

NOTE

Preparation Prior to Installation

Installation

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol **⚠** and the words **WARNING**, **CAUTION** and **NOTE** have special meanings. Pay special attention to the messages highlighted by these signal words:

NOTE: Indicates special information to make maintenance easier or instructions clearer.

1. Park vehicle on a secure service stand and allow engine to cool fully before attempting installation.

1. Loosen stock brake clevis locknut.

2. Remove cotter pin and clevis pin.

3. Remove stock brake clevis and install Yoshimura Suzuki brake clevis.

NOTE: Lock nut torque spec is 4.5 Ft/Lb (6 Nm). Replacement of cotter pin used to secure the clevis pin is recommended.

Inspection/Adjustment

1. Periodically check tightness of lock nut.

⚠ WARNING

Indicates a potential hazard that could result in death or injury

CAUTION

Indicates a potential hazard that could result in vehicle damage.