



YOSHIMURA

RESEARCH & DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CA. 91710 · (800)634-9166 · (909)628-4722 · FACSIMILE (909)591-2198

www.yoshimura-rd.com

RS7 REPACKING KIT

REPACK-RS7

RS7 Repacking Kit



Parts Included

NO.	DESCRIPTION	QTY	PART #
1	Packing	1	PACKING2
2	Stainless Steel Rivets	10	C3-RIVET
3	Stainless Steel Rivet Band	2	RB002
4	Yoshimura Vinyl Sticker	2	17028-BLK

Caution: Exhaust system can be extremely hot. Let motorcycle cool down before beginning installation. Always wear hand and eye protection and take precautionary measures to avoid injury.

Tools Needed:

Drill
3/16" Drill Bit
Rubber Hammer
Rivet Gun
Sharp Punch
Steel Hammer
High Temperature Silicon

Installation Steps:

WARNING: We recommend that you wear a mask and proper eye protection while disassembling and repacking the muffler. Fiberglass may irritate your eyes and skin.

1. Use the sharp punch and steel hammer to punch out the center of each rivet on both ends of the muffler (as shown in figure 1). (DO NOT remove the rivets holding the name plate on, no name plate or name plate rivets are included in this kit).
2. Using the 3/16" drill bit and drill, drill through the center of each of the rivets (as shown in figure 2).

NOTE: We recommend drilling slowly through the rivets, they are made from stainless steel and are very hard. Make sure you also use lubrication while drilling.

3. Using the punch go through each rivet hole making sure all the rivets have properly drilled through.
4. Grab the muffler by the end cap while using the rubber hammer to gently hit the mounting point on the sleeve to break the end cap free (as shown in figure 3).
5. Repeat step 4 for front side of muffler.
6. When everything is apart make sure to clean and inspect everything: i.e. Make sure there are no cracks, clean all the carbon build up off the baffle and make sure the stainless steel mesh is in good condition.



7. Before you start to install the new packing make sure everything is completely dry (wet packing will make your Motorcycle or Quad louder).
8. Wrap the whole bag around the baffle tightly, then insert the baffle and packing together into the sleeve (as shown in figure 4).
9. Once you have the front cap and packing in the sleeve there will be more left over, this packing is to fill in the gap at the end of the muffler. By using your hand or a tool, pack the rest of the packing around the baffle until the sleeve is full (as shown in figure 5).
10. Install the end cap and all the C3 rivets provided to you (as shown in figure 6).

NOTE: Make sure you reinstall the new rivet bands on the front and rear side of the muffler. Make sure that all your rivets are properly installed.

11. Using high temperature silicon sealer, seal the front cap (as shown in figure 7). Wipe the excess silicon off and let the silicon dry before running it on your Motorcycle or Quad.
12. Before starting the motorcycle, check if all hardware is tight. If any problem is found, please carefully follow through the installation steps again. If problem still persists, please call Yoshimura Technical Department at (800) 634-9166 / in CA (909) 628-4722.

