



# YOSHIMURA

RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CA., 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198

[www.yoshimura-rd.com](http://www.yoshimura-rd.com)


## **TURN SIGNAL ADAPTER PLATES**

### **Kawasaki**

**KLX 300S**

**KLX 300SM**

**073BG143020**



No.	Item	Description	Qty.
1	073BG143020-B	Front Turn Signal Plate	2
2	073BG143020-IN	Metal Inner Back Plate	2
<b>Optional Recommended Accessories</b>			
	072BGLTSFK	Yoshimura LED Front Turn Signal Kit	
	072BGLTSFK-S	Yoshimura Sequential LED Front Turn Signal Kit	
	072BGLTSR	Yoshimura LED Turn Signal Kit w/ Relay	
	072BGLTSR-S	Yoshimura Sequential LED Turn Signal Kit w/ Relay	

**IMPORTANT:** Installation of this product requires the use of aftermarket M8 mounted turn signals.  
Not compatible with stock turn signals.

## Removal

1. Remove the two mounting bolts for the headlight assembly, one on each side.



RIGHT SIDE EXAMPLE SHOWN

2. Disconnect and remove the headlight assembly.
3. Locate and disconnect the turn signal connectors.
4. Remove the turn signals.

## Installation

1. Install *073BG143020-B*, turn signal plate from the outside and *073BG143020-IN* metal back plate from the inside to install the aftermarket turn signal. Secure using turn signal washer and nut.
2. Repeat steps for opposite side.
3. Re-connect turn signal connectors.

Note: *073BG-KAW* turn signal adapter wires are available for purchase separately for direct plug-and-play alternative with Yoshimura LED turn signals.

4. Check for proper function of turn signals and that all components are secure prior to riding. Adjust turn signal rotation as needed and tighten turn signal nut.