



YOSHIMURA


RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CA., 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198

www.yoshimura-rd.com

TURN SIGNAL ADAPTER PLATES

Honda CRF300L Rally 073BG123420



No.	Item	Description	Qty.
1	073BG123420	Front Turn Signal Plate	2
2	073BG123420-IN	Front Inner Plate	2
OPTIONAL RECOMMENDED ACCESSORIES			
	RLYG2	Flasher Relay	
	072BGLTSFK-S	Yoshimura Sequential LED Turn Signal Kit	
	072BGLTSFK	Yoshimura LED Turn Signal Kit	

IMPORTANT: Installation of this product requires the use of aftermarket M8 mounted turn signals.
Not compatible with stock turn signals.

Removal

1. Follow steps in factory service / owners manual to remove the windscreen and headlight assembly.
2. Locate, identify, and disconnect the turn signal connectors from the harness.
3. Remove left and right turn signals from the turn signal holders.
4. Cut the turn signal wires 4" from the male connector and strip the ends.


Note: Daytime Running Light functionality will be lost.

Installation

1. Insert the front turn signal plate and inner onto the turn signal holder and install aftermarket turn signal. Secure using washer and nut.

Rear of Bike

Front of Bike



RIGHT SIDE EXAMPLE SHOWN

2. Using the solder shrink connectors supplied in the micro turn signal kit, connect turn signal wires to micro light wires as follows:

Right:
Black (Harness) - Black
Gray (Harness) - Red

Left:
Black (Harness) - Black
Gray (Harness) - Red

a) Strip the stock turn signal wire ends 1/4" - 1/2" and insert into *BN-SSS-22-18*, solder shrink connectors provided in the kit.

b) Center the spliced wire ends in the middle and using a heat gun or lighter, apply heat evenly on the outer edges of the solder shrink connector to shrink and hold wires in place.

- c) Making sure that the stripped ends are centered, heat the center of the solder shrink connector evenly until the solder begins to liquify.
- d) Allow to cool completely and tug both ends of the wires to verify that connection is secured.

Scan for link to solder shrink connector instruction video.



3. Repeat steps for opposite side.
4. Check for proper function of turn signals and that all components are secure prior to riding.
5. Re-install the headlight assembly and windscreen using the reverse steps of removal.

IMPORTANT NOTE:

****RLYG2**, flasher relay is recommended for proper turn signal flash and is sold separately. Please see the appendix below for turn signal relay installation.

**** [Turn Signal Relay Installation](#) ****