



YOSHIMURA


RESEARCH&DEVELOPMENT OF AMERICA,

5420 DANIELS STREET STE A, CHINO CA., 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198

www.yoshimura-rd.com

MICRO TURN SIGNAL ADAPTER PLATES

SUZUKI GSX-8T / GSX-8TT 074BG117300



No.	Item	Description	Qty.
1	074BG117300-B	Front Turn Signal Plate	2
2	072BGMICRTSR	Micro LED Turn Signal Kit	1
3	6MMWASHERL	6mm Flat Washer - Large	2
4	M6X16BHS	6mm X 16mm Button Head Cap Screw	2
5	6MMLN	M6 X1.0 Nylon Lock Nut	2

Removal

**** GSX-8T ****

1. Remove the headlight shroud.
2. Remove the turn signal holder. (Push pin by the meter display, turn signal holder's mounting bolts, and 2 pull-out tabs underneath the headlight).
3. Locate and disconnect turn signal connectors.
4. Remove turn signals from the turn signal holder.
5. Cut the turn signal wire 4" from the turn signal connector, not the wiring harness connector.

**** GSX-8TT ****

1. Remove the headlight cowl (2 bolts and 6 push pins.


Note: Once the mounting hardware is removed, carefully pull from the windscreen, then pull from the bottom of the headlight cowl once the cowl hinges from the bottom two mounting studs.
2. Locate and disconnect turn signal connectors.
3. Remove turn signals from the turn signal holder.
4. Cut the turn signal wire 4" from the turn signal's connector, NOT the wiring harness connector.

Installation

1. Place the micro turn signal in the smaller hole and plastic hex nut inside the pocket of 074BG117300-B, front turn signal plate.

Note: Proper positioning of the micro turn signal in the adapter plate is dependent on the orientation of the plastic nut. If the turn signal is not facing forwards, rotate the plastic nut in the adapter plate pocket and re-install until the turn signal is facing forward.

Rear of Bike



Front of Bike

RIGHT SIDE EXAMPLE SHOWN

2. Insert the turn signal plate onto the outside of the turn signal holder where the stock turn signal was removed. Secure using *M6X16BHS*, button head screw, *6MMWASHERL*, 6mm washer, and *6MMLN*, nylon lock nut.
3. Using the solder shrink connectors supplied in the micro turn signal kit, connect the turn signal wires to micro light wires as follows:

Right:

Black and White - Black
Blue - Blue

Left:

Black and White - Black
Black - Blue

- a) Strip the stock turn signal wire ends 1/4" - 1/2" and insert into *BN-SSS-22-18*, solder shrink connectors provided in the kit.
- b) Center the spliced wire ends in the middle and using a heat gun or lighter, apply heat evenly on the outer edges of the solder shrink connector to shrink and hold wires in place.
- c) Making sure that the stripped ends are centered, heat the center of the solder shrink connector evenly until the solder begins to liquify.
- d) Allow to cool completely and tug both ends of the wires to verify that connection is secured.

Scan the QR code below for link to solder shrink connector instruction video.



Scan QR code on the micro turn signal packaging for wiring diagram.

Note¹: The white running light wire and red brake light wire on the micro signals will not be used. Bundle back up and tuck away.

Note²: A red front light is prohibited in most states. Check with local laws and regulations prior to installation.

4. Repeat steps for the opposite side.
5. Reconnect turn signals.
- 6a. GSX-8T: Reinstall the turn signal holder and headlight shroud using the reverse steps of removal.
- 6b. GSX-8TT: Reinstall the headlight cowl using the reverse steps of removal.
7. Check for proper function of turn signals and that all components are secure prior to riding. Adjust turn signal rotation as needed and tighten the turn signal nut.

IMPORTANT NOTE:

****RLGY2**, flasher relay is recommended for proper turn signal flash and is sold separately. Please see the appendix below for turn signal relay installation.

**** [Turn Signal Relay Installation](#) ****