



YOSHIMURA

RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CA., 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198

www.yoshimura-rd.com


TURN SIGNAL ADAPTER PLATES

Kawasaki

KLX 300S

KLX 300SM

074BG143020



No.	Item	Description	Qty.
1	074BG143020-B	Front Turn Signal Plate	2
2	074BG143020-IN	Metal Inner Plate	2
3	072BGMICRTSR	YRD Micro Combo LED Turn Signal Kit	1
4	6MMLN	M6 X 1.0 Nylon Lock Nut	2
5	M6X12BHS	6mm X 12mm Button Head Cap Screw	2

Removal

1. Remove the two mounting bolts for the headlight assembly, one on each side.




RIGHT SIDE EXAMPLE SHOWN

2. Disconnect and remove the headlight assembly.
3. Locate and disconnect the turn signal connectors.
4. Remove the turn signals.
5. Cut turn signal wire 4" from turn signal connector, not the harness connector.

Installation

1. Place the micro turn signal in the smaller hole and plastic hex nut inside the pocket of *074BG143020-B*, front turn signal plate.

Note: Proper positioning of the micro turn signal in the adapter plate is dependent on the orientation of the plastic nut. If the turn signal is not facing forwards, rotate the plastic nut in the adapter plate pocket and try again until turn signal is facing forward.



RIGHT SIDE EXAMPLE SHOWN

2. Insert the turn signal plate onto the outside of the turn signal holder where the stock turn signal was removed. Place *074BG143020-IN*, metal inner plate on the inside of the turn signal holder and orient to match the profile of the turn signal holder and *074BG143020-B*, turn signal plate. Secure the assembly using *M6X12BHS*, button head cap screw and *6MMLN*, nylon lock nut.
3. Using the solder shrink connectors supplied in the micro turn signal kit, connect turn signal wires to micro light wires as follows:

Right (Gray Connector):

Black and Yellow (Harness) - Black
Green (Harness) - Blue

Left (Black Connector):

Black and Yellow (Harness) - Black
Green (Harness) - Blue

- a) Strip the stock turn signal wire ends 1/4" - 1/2" and insert into *BN-SSS-22-18*, solder shrink connectors provided in the kit.
- b) Center the spliced wire ends in the middle and using a heat gun or lighter, apply heat evenly on the outer edges of the solder shrink connector to shrink and hold wires in place.

- c) Making sure that the stripped ends are centered, heat the center of the solder shrink connector evenly until the solder begins to liquify.
- d) Allow to cool completely and tug both ends of the wires to verify that connection is secured.

Scan for link to solder shrink connector instruction video.



Scan QR code on micro turn signal packaging for wiring diagram.

Note¹: The white running light wire and red brake light wire on the micro signals will not be used. Bundle back up and tuck away.

Note²: A red front light is prohibited in most states. Check with local laws and regulations prior to installation.

- 4. Repeat steps for opposite side.
- 5. Re-connect turn signal connectors.
- 6. Reinstall the headlight assembly.
- 7. Check for proper function of turn signals and that all components are secure prior to riding. Adjust turn signal rotation as needed and tighten turn signal nut.